

/ Perfect Welding / Solar Energy / Perfect Charging

Fronius

LET THE SUNSHINE INTO YOUR BATHROOM.

Use solar energy even more efficiently
with the Fronius Ohmpilot.

HEAT WATER

THE INTELLIGENT WAY

Use your solar energy even more efficiently by heating water with the Fronius Ohmpilot. Surplus solar energy is converted into heat, increasing self-sufficiency in the process.

As soon as your photovoltaic system is producing more solar energy than you are using in your home, the Fronius Ohmpilot will transfer the available surplus to a heating element, towel rail or any other ohmic consumer of your choice. When your water is heated with solar energy, your heating no longer needs to be started up during the sunny months. This extends the service life of your heating system.

Thanks to the continuously adjustable regulation from 0 to 9 kW, up to **100 %** of the solar power generated by the PV system can be used in the property.





YOUR ADVANTAGES AT A GLANCE

- / Extend the service life of heating systems
- / Use solar energy in your own home
- / Increase self-consumption
- / Reduce CO₂ emissions




The majority of a household's hot water consumption (Ø) can be covered by solar power

8+ months*




*depends on the climatic conditions in your country

HOT WATER AS A STORAGE MEDIUM




- / An average four-person household with a 300-litre hot water boiler
- / 5 kWp PV system with a Fronius Ohmpilot

The surplus energy obtained in an average day can be used for:

	PV SURPLUS	WATER HEATING
Overcast 	5 kWh	150 litres to 40°C
Slightly cloudy 	10 kWh	170 litres to 60°C
Sunny 	17 kWh	300 litres to 60°C


On average, **50 litres**
of hot water are required for a
single shower.




INCREASED SELF-CONSUMPTION WITH THE FRONIUS OHMPILOT

A sunny day: ☀️

Before the Fronius Ohmpilot is installed



After the Fronius Ohmpilot is installed



The PV system supplies power to the electrical loads in the property while the surplus energy is fed into the public grid.

The surplus power is not fed into the public grid. Instead, it is used by the water heating system by heating the water to a pre-set temperature.

Self-consumption
can be increased

to over **60%**,
even on a
sunny day.





Fronius India Private Limited

GAT no 312, Nanekarwadi
Chakan, Taluka - Khed District
Pune 410501
India
pv-sales-india@fronius.com
www.fronius.in

Fronius Australia Pty Ltd.

90-92 Lambeck Drive
Tullamarine VIC 3043
Australia
pv-sales-australia@fronius.com
www.fronius.com.au

Fronius UK Limited

Maidstone Road, Kingston
Milton Keynes, MK10 0BD
United Kingdom
pv-sales-uk@fronius.com
www.fronius.co.uk

Fronius International GmbH

Froniusplatz 1
4600 Wels
Austria
pv-sales@fronius.com
www.fronius.com